

### Deck Side Installation

1. Place the next deck kit up against the assembled deck as pictured below.



2. Install the spreaders against the 1<sup>st</sup> assembled deck kit



3. Once the rim board is installed on the 2<sup>nd</sup> deck, screw the two rim joints together to connect the two decks



4. Install connector screws as indicated. We recommend a minimum of 6 screws to join the two decks.



### Deck End Installation

The rim board comes factory installed, to connect the two decks screw the rim boards together as shown below.

